

Lune Chandelier and Semi Flush Mount

EC1246, EC1258, EF1063 | 1.0

VISUAL COMFORT & Co.

STUDIO COLLECTION

GENERAL PRODUCT INFORMATION:

These fixtures are intended to be installed utilizing NEC compliant junction boxes.

This product is safety listed for damp locations.

Incandescent version may be dimmed with a standard incandescent dimmer. LED version may be dimmed with a LED dimmer. Consult lamp manufacturer for additional information.


This instruction shows a typical installation.

CAUTION - RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Use minimum 90°C supply conductors.

SAVE THESE INSTRUCTIONS!



Install the Fixture



- 1** Secure the mounting plate to the junction box.
- 2** Screw the half ball to the stem which will be on top.
- 3** Determine the wanted height or look of the fixture with the provided stems, then assemble them by screwing them together.
- 4** Feed the fixture wires through the stem assembly, then screw the stem assembly to the top of the socket assembly.
- 5** Feed the fixture wires through collar nut, canopy and the half ball assembly, then screw the half ball assembly onto the stem assembly.
- 6** Slide the half ball assembly onto the screw collar on the mounting plate.
- 7** Connect the fixture to a suitable ground in accordance to local electrical codes.
- 8** Connect the white fixture wire (square and/or rigid) to the neutral power line wire with a wire nut.
- 9** Connect the black fixture wire (round and/or smooth) to the hot power line wire with a wire nut.
- 10** Neatly place all the wires into the junction box, place the canopy onto the mounting plate and secure it in place by screwing the collar nut tightly onto the mounting plate.
- 11** Install the lamps by inserting the lamp pins completely into the sockets. Refer to the label on the socket for Max Wattage Information.
- 12** Install the shade by screwing it onto the threaded socket until secure. Repeat for remaining shades.