

KENYON TASK FLOOR LAMP

CT1161

General Product Information

Go to www.visualcomfort.com for product specs.



SAVE THESE INSTRUCTIONS!



INDOOR




DRY LOCATION




BULB(S)
(NOT INCLUDED)



CONVERTS TO LED



POLARIZED PLUG



BEST PRACTICE:
HANDLE FIXTURE
WITH GLOVES



CLEAN WITH SOFT,
DRY CLOTH ONLY. NO
HARSH CHEMICALS!



Product Warranty



FCC Statement

Safety Information


IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.




Turn off electrical current at the source before working with any lighting fixture or portable lamp.

Install and use this product in adherence with local electrical codes and regulations.



FIXTURE PARTS

- A. Shade
- B. Bulb (Not Included)
- C. Switch
- D. Fixture Arm
- E. Stem Assembly
- F. Nipple
- G. Lamp Base
- H. Washer
- I. Hex Nut
- J. Power Cord with Polarized Plug



INSTRUCTIONS

1. Remove the lamp and all its parts from the packaging.
2. Assemble the fixture stems together by screwing the together.
3. Insert the nipple of the bottom stem into the lamp base.
4. Adjust the assembled lamp body accordingly and secure it with the provided washer and hex nut.
5. Screw the light bulb into the socket under the lamp shade. Refer to the socket label for max wattage information.
6. Remove the protective plug cover from the plug portion of the power cord and plug it into a functioning electrical outlet.
7. Use the switch to turn the lamp on and off to test that it functions properly.