



ASSEMBLY INSTRUCTIONS FOR Sonora Table Lantern

Model # 3010-15

3010-15 1.0



Screw bulb (B) clockwise into socket (A) to tighten.
Bulb (B) not included.



GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER THE PLUG.**

BULB TYPE: (1) 60 watt incandescent or
9 watt LED equivalent.(not included)