

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING AND KEEP THIS MANUAL FOR FUTURE USE & REFERENCE.

PACKAGE CONTENTS:


1. Jellyfish Motion Light Box
2. Requires (4) - 1.5V AA batteries (not Included)
3. Maximum DC 5V 400mA adaptor (Included)
4. 8 feet USB cord (Included).

PRODUCT USAGE INSTRUCTIONS:


1. Use by battery power (see Battery Info section) OR plug in with included adaptor. If you use both at the same time, the power will come from the adaptor
2. The product must be placed upright and must not be tilted or knocked down. Because the water in the tank is not sealed, it can overflow if it is tilted or knocked down.
3. Please add water to the highest water level according to the water line. Do not fill water to the top of the frame or it will bubble over when turned on.
4. When the water is under the lowest water level, please add water in time.

BATTERY INSTRUCTION


- Step 1.**
Open the battery cover.




- Step 2.**
Put 4*AA battery into the battery case according to the positive and negative anodes.




- Step 3.**
Twist screw of the battery case on fully.




- Step 4.**
Open the cover of the water box.




- Step 5.**
Pour pure water to the water level line in the box.




- Step 6.**
Add 3-4 drops dish detergent into the water box.




- Step 7.**
Put 3 jellyfishes in to the water box orderly.



- Step 8.**
Stir the liquid moderately and remove the bubbles from the jellyfish's heads.




- Step 9.**
Close the cover of the water box.



WALL MOUNT ASSEMBLY INSTRUCTIONS

1. Cut out the blow hole size guideline according to the dotted line.
2. Place the hole size guideline on the wall, then mark the hole in the wall.
3. Drill two light hole, then align holes with plastic bolts and attach with 2 screws. Secure screws with a Phillips head screwdriver
4. Hang the lamp onto the wall.



CARE INSTRUCTIONS:

1. Place the unit on a flat, dry and sturdy surface.
2. To clean the unit, use a dry cloth. DO NOT submerge in water.
3. DO NOT open the case of the unit as there are no user replacement parts.
4. This product is intended for personal indoor household use only - DO NOT use outdoor.
5. Keep product out of reach of small children and pets. THIS IS NOT A TOY.
6. Handle product with care.
7. A note on packaging: Due to the fragile nature of this product, we have chosen to use Styrofoam only where it is needed to protect it and deliver the best quality product to our customer. We are aiming to reduce the use of plastic and styrofoam in the packaging of our products where possible and are investigating more environmentally friendly alternatives to use. We hope you enjoy your purchase!

