


Judith Floor Lamp

Model # 3767-12



1. Remove all parts and lay on a flat surface.
2. Screw pole(B) clockwise into base(A) to tighten. Then pull the remaining slack of the power cord out carefully through base.
3. Screw wood pole(C) clockwise into pole(B) to tighten.
4. Screw pole(D) clockwise into wood pole(C) to tighten.
5. Place wood part(E) into pole(D).
6. Screw pole(F) clockwise into wood part(E) to tighten.
7. Socket ring(H) comes pre-assembled to the socket. Before assembling the shade(G), please unscrew this socket ring(H). Set shade(G) onto socket and tighten clockwise with socket ring to secure shade.

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

BULB TYPE: (1) 150 watt 3-way incandescent or
18 watt 3-way LED bulb. (not included)

A note on packaging: Due to the fragile nature of this product, we have chosen to use Styrofoam only where it is needed to protect it and deliver the best quality product to our customer. We are aiming to reduce the use of plastic and styrofoam in the packaging of our products where possible and are investigating more environmentally friendly alternatives to use. We hope you enjoy your purchase!