


ASSEMBLY INSTRUCTIONS FOR ELI FLOOR LAMP

Model # SL9504-01 / SL9504-21

SL9504-01 1.0
SL9504-21



1. Assemble the Fixture by screwing the stems (B) together, then screwing the stems (B) to the socket assembly (C) and fixture base (A).
2. Install the Harp (F) by inserting it into the Yoke (D).
3. Install the bulb (Not Included) by screwing it into the socket (E). Refer to the label on the lamp socket for Maximum wattage information.
4. Install the shade (G) by unscrewing the finial (H) from the harp (F), placing the shade (G) over the threaded nipple, and re-tightening the finial (H) to secure the shade (G).

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug.

If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted.

DO NOT ALTER THE PLUG.

BULB TYPE: (1) 150 Watt 3-Way Medium Base

simplee
A D E S S O

353 West 39th Street, 2nd Floor
New York, NY 10001
Tel: (212) 736 4440 Fax: (212) 736 4806
www.adessohome.com