


ASSEMBLY INSTRUCTION FOR

Joey Floor Lamp

Model# 1616-21



PARTS DIAGRAM

- 1 - Base (A)
- 2 - bolt (B)
- 2 - Tube (C)
- 2 - Tube (D)
- 2 - Tube (E)
- 1 - Part (F)
- 1 - Socket Assembly (G)
- 1 - Shade (H)
- 1 - Socket Ring (I)

1. Fasten tubes (E) onto Part(F).
2. Fasten tubes (D) onto tube(E).
3. Fasten tubes (C) onto tube(D).
4. Stand lamp up and place tubes(C) onto lamp base (A). Gently screw bolts (B) onto base (A) to secure the tubes to the base.
5. Socket ring (I) comes pre-assembled to the socket (G). Before assembling the shade, please unscrew this socket ring (I). Place shade (H) onto socket assembly (G).
6. Tighten socket ring (I) onto socket assembly (G) to secure shade.

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted.
DO NOT ALTER THE PLUG .

BULB TYPE: Please use 100 Watt Incandescent or 16Watt LED Bulb (Not Included).

ADESSO

353 West 39th Street 2nd Floor NY, NY 10018
Tel: (212) 736 4440 Fax: (212) 736 4806
www.adessohome.com

INSTRUCCIONES DE ENSAMBLAJE PARA

Joey Lámpara de Piso

Modelo#1616-21




DIAGRAMA DE LAS PIEZAS

- 1 - Base (A)
- 2 - perno(B)
- 2- Poste (C)
- 2 - Poste (D)
- 2 - Poste (E)
- 1 - Parte (F)
- 1 - Boquilla (G)
- 1 - Pantalla (H)
- 1 - Anillo (I)

1. Coloque el poste (E) en el Parte(F) 1. Enrosque los postes (E) en la parte (F).
2. Enrosque los postes (D) en el poste (E) .
3. Enrosque los postes (C) en el poste (D).
4. Levante la lámpara y coloque los postes (C) en la base de la lámpara (A). Atornille suavemente los pernos (B) en la base (A) para asegurar los postes en la base.
5. El anillo de la boquilla (I) viene pre-montado en la boquilla (G). Antes de colocar la pantalla, desenrosque el anillo (I). Coloque la pantalla (H) en la boquilla (G).
6. Enrosque el anillo (I) en la boquilla (G) para asegurar la pantalla.

INFORMACION GENERAL DEL PRODUCTO:

Este producto es adecuado sólo para lugares secos.

INSTRUCCIONES IMPORTANTES DE SEGURIDAD:

Esta lámpara portátil tiene un enchufe polarizado (una paleta es más ancha que la otra), función de seguridad que reduce el riesgo de una descarga eléctrica. Este enchufe encajará en un tomacorriente polarizado en un sólo sentido. Si el enchufe no entra completamente en el tomacorriente, invierta el enchufe. Si aún así no encaja, llame a un electricista calificado. Nunca use un cable de extensión a menos que el enchufe pueda insertarse por completo. **NO MODIFICAR EL ENCHUFE.**

TIPO DE BOMBILLA: Utilice una bombilla incandescente de 100 vatios o una bombilla LED de 16 vatios (no incluida).

ADESSO

353 West 39th Street 2nd Floor NY, NY 10018
Tel: (212) 736 4440 Fax: (212) 736 4806
www.adessohome.com