


Daniel Floor Lamp

Model# 4176-01



GET INSPIRED. SHARE YOUR STYLE.

#myadesso

Visit www.adessohome.com for details.

1. Screw pole (B),(C), (D) and (E) together.
2. Screw pole (B) onto base (A) clockwise until tight. You may need to pull any excess cord gently through the base so that these two parts fit.
3. Socket ring comes pre-assembled to the socket. Before placing the shade onto the socket, please unscrew this socket ring.
4. Place shade (F) onto socket and tighten it with socket ring (G).

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.




IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG.**

BULB TYPE: Use only with 3pcs type A Max 60W bulb (not included).

Daniel Lámpara de Piso

Modelo# 4176-01



INSPIRATE. COMPARTE TU ESTILO

#myadesso

Visite www.adessohome.com para detalles.

1. Enrosque los postes (B), (C), (D) y (E) juntos.

2. Enrosque el poste (B) en la base (A) hacia la derecha hasta que quede apretado.

Es posible que deba halar suavemente el cable sobrante a través de la base para que encajen estas dos partes.

3. El anillo de la boquilla viene premontado en la boquilla. Desenrosque el anillo antes de colocar la pantalla en la boquilla.

4. Coloque la pantalla (F) en la boquilla y apriétela con el anillo (G).

INFORMACION GENERAL DEL PRODUCTO:

Este producto es adecuado sólo para lugares secos.



INSTRUCCIONES IMPORTANTES DE

SEGURIDAD: Esta lámpara portátil tiene un enchufe polarizado (una paleta es más ancha que la otra), función de seguridad que reduce el riesgo de una descarga eléctrica. Este enchufe encajará en un tomacorriente polarizado en un sólo sentido. Si el enchufe no entra completamente en el tomacorriente, invierta el enchufe. Si aún así no encaja, llame a un electricista calificado. Nunca use un cable de extensión a menos que el enchufe pueda insertarse por completo. **NO MODIFICAR EL ENCHUFE.**

TIPO DE BOMBILLA: Use sólo con 3 bombillas tipo A de 60 vatios máximo (no incluida).

ADESSO®353 West 39th Street, 2nd Floor, New York, NY 10018

Tel: (212) 736 4440 Fax: (212) 736 4806

www.adessohome.com