


ASSEMBLY INSTRUCTIONS FOR Rhodes Chandelier

3938-21 1.0

Model # 3938-21


Step 1.

1. Screw pole(F) clockwise into part(H) to tighten.
2. Screw pole(E) clockwise into pole(F) to tighten.
3. Screw pole(C) clockwise into pole(E) to tighten.
4. Screw canopy(A) clockwise into pole(C) to tighten.
5. If need to adjust the hight, take pole from the lamp and assembly the lamp as shown. Screw screw nut(D2) clockwise into pole(F) to tighten. Screw screw nut(D1) clockwise into pole(E) to tighten.




Step 4.

Attach the neutral fixture wire (N) from the pendant to the neutral wire in junction box (usually white).
Attach the hot fixture wire (L) from the pendant to the hot wire in junction box (usually black).
Cover the connected wires with part (M) - tighten each connection by turning clockwise.
Twist both ground wire with wire nut (M).




Step 3.

Find your ground wire, hot wire and neutral wire in your junction box and pull them through the central round hole of bracket. Fasten Bracket (B) into junction box with 2 screws (O) to tighten.




Step 6.

Socket ring(J) comes pre-assembled to the socket. Before placing the shade onto the socket, please unscrew this socket ring(J). Place shade(I) onto the socket and tighten clockwise with socket ring(J) to secure shade.




Step 2.

After finish the step 1, remove 2 screws(K) from the canopy (A), remove Bracket (B)



Step 5.

Push up the canopy (A) to cover Bracket (B) properly and fasten with the 2 screws (K) separately to tighten.



PARTS DIAGRAM:

- (3) Screws (O)
- (3) Wire nut (M)

GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

BULB TYPE: (5) 40 watt incandescent or 9 watt LED bulb (not included)

A note on packaging: Due to the fragile nature of this product, we have chosen to use Styrofoam only where it is needed to protect it and deliver the best quality product to our customer. We are aiming to reduce the use of plastic and styrofoam in the packaging of our products where possible and are investigating more environmentally friendly alternatives to use. We hope you enjoy your purchase!

ADESSO

353 West 39th Street, 2nd Floor, New York, NY 10018

Tel: (212) 736 4440 Fax: (212) 736 4806

www.adessohome.com