


ASSEMBLY INSTRUCTIONS FOR CLAREMONT FLOOR LAMP

9401-21 1.0

Model # 9401-21



1. Assemble the Fixture by screwing the stems together, then screwing the stems to the socket assembly and fixture base.
2. Install the Harp by inserting it onto the socket assembly.
3. Install the bulb (Not Included) by screwing it into the socket. Refer to the label on the lamp socket for Maximum wattage information.
4. Install the shade by unscrewing the finial from the harp, placing the shade over the threaded nipple, and re-tightening the finial to secure the shade.

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

BULB TYPE: (2) 60Watt Medium Base

PARTS DIAGRAM:

Wrench
(2) Screws
(2) Lock Washers
(2) Washers