

ASSEMBLY INSTRUCTION FOR Colby LED Floor Lamp

4275-01

1.0

Model# 4275-01

1. Screw poles (A), (B), (C) and (D) together.

2. Remove the bushing (E) from the base and throw away.

3. Insert tube (D) to base (F) & washer (G), then tighten it with nut (H) using wrench (I). You may need to pull any excess cord gently through the poles so that these two parts fit.

Note: The lamp should face forward in the same direction as the switch, with the cord coming out of the back of the base.



GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG.**



GET INSPIRED. SHARE YOUR STYLE.

#myadesso

Visit www.adessohome.com for details.

Colby Lámpara LED de Piso

Modelo# 4275-01

1. Enrosque juntos los postes (A), (B), (C) y (D).

2. Retire el casquillo (E) de la base y deséchelo.

3. Inserte el tubo (D) y la arandela (G) en la base (F), luego apriételo con la tuerca (H) usando la llave (I). Es posible que tenga que halar suavemente el exceso de cable a través de los postes de manera que estas dos piezas encajen.

Nota: La lámpara debe mirar hacia adelante en la misma dirección que el interruptor, con el cable saliendo por la parte posterior de la base.



INFORMACION GENERAL DEL PRODUCTO:

Este producto es adecuado sólo para lugares secos.



INSTRUCCIONES IMPORTANTES DE SEGURIDAD :

Esta lámpara portátil tiene un enchufe polarizado (una paleta es más ancha que la otra), función de seguridad que reduce el riesgo de una descarga eléctrica. Este enchufe encajará en un tomacorriente polarizado en un sólo sentido. Si el enchufe no entra completamente en el tomacorriente, invierta el enchufe. Si aún así no encaja, llame a un electricista



! INSPIRATE Y COMPARTE TU ESTILO ;

#myadesso

Visite www.adessohome.com para más detalles

ADESSO®

353 West 39th Street, 2nd Floor, New York, NY 10018
Tel: (212) 736 4440 Fax: (212) 736 4806
www.adessohome.com