


ASSEMBLY INSTRUCTIONS FOR Harriet LED Floor Lamp

3698-21 1.0

Model # 3698-21



1. Screw pole(B) clockwise onto base(A) to tighten.
2. Screw pole(C) clockwise onto pole(B) to tighten.
3. Screw socket part(D) clockwise onto pole(C) to tighten.
4. Attach each glass shade(E) by lining up the 3 points in the socket with the glass, and turn clockwise until the shade clicks into place.
5. Assemble the transformer(F) and plug in.

A note on packaging: Due to the fragile nature of this product, we have chosen to use Styrofoam only where it is needed to protect it and deliver the best quality product to our customer. We are aiming to reduce the use of plastic and styrofoam in the packaging of our products where possible and are investigating more environmentally friendly alternatives to use. We hope you enjoy your purchase!

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER THE PLUG.**

LED: 30 watt LED included.