


Wentworth Floor Lamp

Model# 5039



GET INSPIRED. SHARE YOUR STYLE.

#myadesso

Visit www.adessohome.com for details.

1. Screw 4 tubes (B) into base (A) clockwise to tighten.

2. In order to screw on tubes (B),(C),(D) and (E), you will need to alleviate the excess cord. You will now need to lay the lamp on its side to reach the bottom of the base. Pull each black cord gently from the bottom of the base through the poles.

You can hide the excess cord under the black metal plate on the bottom of the base. Please be sure the cord is packed flat under the black metal base plate for optimum stability.

3. Socket ring comes pre-assembled to the socket. Before placing the shade onto the socket, please unscrew this socket ring.

4. Place shade (F) onto socket (E) and tighten it with socket ring (G).

GENERAL PRODUCT INFORMATION

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG.**


BULB TYPE:

Use only with maximum of 3*40 watt incandescent bulbs .. (bulbs not included)

Must use all incandescent or all LED bulbs.

Wentworth Lámpara de Piso

Modelo# 5039



INSPIRATE. COMPARTE TU ESTILO

#myadesso

Visite www.adessohome.com para detalles.

1. Enrosque los 4 tubos (B) en la base (A) hacia la derecha hasta que queden apretados.

2. Para atornillar los tubos (B), (C), (D) y (E), deberá aliviar el exceso de cable.

Ahora deberá colocar la lámpara de lado para llegar a la parte inferior de la base. Hale suavemente cada cordón negro desde la parte inferior de la base a través de los postes.

Puede ocultar el exceso de cable debajo de la placa de metal negro en la parte inferior de la base.

Asegúrese de que el cable esté plano debajo de la placa de metal negro para una estabilidad óptima.

3. El anillo de la boquilla viene preensamblado en la boquilla. Antes de colocar la pantalla en la boquilla, desenrosque el anillo.

4. Coloque la pantalla (F) en la boquilla (E) y apriétela con el anillo (G).

INFORMACION GENERAL DEL PRODUCTO

Este producto es adecuado sólo para lugares secos.



INSTRUCCIONES IMPORTANTES DE SEGURIDAD:

Esta lámpara portátil tiene un enchufe polarizado (una paleta es más ancha que la otra), función de seguridad que reduce el riesgo de una descarga eléctrica. Este enchufe encajará en un tomacorriente polarizado en un sólo sentido. Si el enchufe no entra completamente en el tomacorriente, invierta el enchufe. Si aún así no encaja, llame a un electricista calificado. Nunca use un cable de extensión a menos que el enchufe pueda insertarse por completo. **NO MODIFICAR EL ENCHUFE.**

TIPO DE BOMBILLA:

Use sólo 3 bombillas incandescentes de 40 vatios máximo (bombillas no incluidas)

Debe usar todas las bombillas incandescentes o LED.

ADESSO®353 West 39th Street 2nd Floor New York, NY 10018

Tel: (212) 736 4440 Fax: (212) 736 4806

www.adessohome.com