


CRYSTORAMA LIGHTING



Crystorama.com

ASSEMBLY INSTRUCTION MODEL #OAK-7539-SG




All electrical components must be installed by a licensed electrician in accordance with the National Electric Code and the appropriate local electrical codes.



FIXTURE USES INTEGRATED LEDS(INCLUDED)
50 WATTS MAX
THIS FIXTURE IS DRY RATED

How to install

1. Decide the preferred hanging height and choose the correct length of chain and fixture wire. When cutting the fixture wire, remove any stickers, on the section being removed, one at a time to ensure the stickers can be put back correctly.
2. Remove the open hook on the rod then thread the wires through the open hook and then the rod. Tighten the open hook and rod back together. Run the wires through the chain, loop and canopy and insert the buckle on the end of the wires. Make sure to leave enough wire to connect with the CCT driver.
3. Take the end of the rod with an open hook and attach it to the top of the fixture frame then attach the other end onto the loop kit.
4. Connect the fixture wires to the CCT switch following the wiring diagram on the following page matching the letter on the wire sticker with the letter on the CCT switcher sticker. Set the color temperature at this step by sliding the button to the desired color temperature (2700k or 3000k).
5. Raise the fixture up to the ceiling and connect the driver's wires with the house wire. Secure the canopy with screws.



WARNING: This product can expose you to Lead, which is known to the State of California to cause cancer and/or birth defects or reproductive harm. For more information go to www.P65Warnings.ca.gov.

CRYSTORAMA LIGHTING



PART NUMBER MODEL #OAK-7539-SG

Part Number

- A. (1) - Mounting Hardware
- B. (1) - Canopy(W7.50",H1.8") #XRE7539SGCAN7.5IN
- C. (2) - Fixture Loop
- D. (2) - Quick Link
- E. (1) - Hanging Chain(72",5.0mm) #XRE7539SGCHA5.0MM
- F. (1) - Loop Kit
- G. (3) - Rod(34",9.3mm) #XRE7539STEM34IN
- H. (1) - Frame

