


ASSEMBLY & INSTALLATION INSTRUCTIONS

C22

232810 & 272800 Antasia Portables



232810



272800



HUBBARDTON FORGE.

MODERN AMERICAN BLACKSMITHS | FINE, HAND CRAFTED LIGHTING
CASTLETON, VERMONT USA | HUBBARDTONFORGE.COM

19917 Rev B

1 OF 3

Component Parts

- A Finial
- B Washer
- C Diffuser
- D Shade
- E Harp
- F Socket Knob
- G Harp Holder
- H Socket
- I Locks (2)

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Install Shade & Diffuser (Figures 1 - 3)

1. Carefully unpack the fixture from the carton.
2. Install socket knob (F) onto socket (Figure 1).
3. Remove finial (A) from harp (E) and save for later use. Finial is shipped installed on harp.
4. Squeeze harp (E) together while holding the locks (I) up towards the top of the harp (E) and slip into harp holder (G) (Figure 1).
5. Allow locks (I) to slip down harp (E) and onto harp holder (G) to secure harp in place.
6. Install bulb, (not included).
7. Slip shade (D), diffuser (C) and washer (B) onto threaded stud on top of harp (E). See Figure 3 for washer orientation.
8. Thread finial (A) onto threaded stud on harp (E) and tighten until snug. Be careful not to over tighten.

