

Glass Installation Instructions

B36


Please refer to fixture assembly and installation instructions prior to glass installation.

Component Parts

- A** Glass
- B** Socket
- C** Retaining Ring

To Install Glass

1. Remove Retaining Ring (C) from Socket (B).
2. Place Glass (A) over Socket, and secure with Retaining Ring (C).



If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!